

Installation & Operation



The original, trademarked Fumoto® valve is a tried and true design that will make your oil changes Simply Effortless.

Installation

- 1 Prepare:** Remove the drain plug from your oil pan and drain oil completely. Be sure that the surface of your oil drain port is clean before proceeding with installation.
- 2 Assemble:** Place the blue fiber gasket (not required for tapered thread or O-ring valves) onto the valve so it will sit flat between the oil pan and the valve once installed.
- 3 Hand-Tighten:** Begin gently threading the valve into your oil drain port by hand. Once you have ensured that the valve is straight and not cross-threaded, hand-tighten completely.
- 4 Torque:** Tighten the valve with a crescent wrench *on the body of the valve** an additional 1/8 to 1/4 turn. Do not over tighten.

** Do not use a wrench on the hex head if present*


***An adapter may be required if the valve cannot be completely tightened due to contact with the oil pan.*

- 5 Close and lock:** Close the valve by firmly turning the control lever clockwise until it stops and is perpendicular to the oil outlet. The lever will click into the recess and lock in position. You should not be able to rotate the lever without first lifting upward.

- 6 Clip on and fill up:** Install a lever clip if desired around the turret of the valve. If the lever is not seated properly, the lever clip will not fit. Refill the oil to complete your oil change. Always inspect the oil pan for leaks before operating your vehicle.



Operation



OPEN

To open the valve, remove the lever clip if installed then lift the control lever upward and turn 90° counterclockwise.

CLOSE

To close the valve, turn the control lever firmly clockwise until it stops and is perpendicular to the oil outlet. The lever will click into the recess and lock in position. You should not be able to rotate the lever without first lifting upward. Reinstall the lever clip if desired around the turret of the valve. If the lever is not seated properly, the lever clip will not fit. Always inspect the oil pan for leaks before operating your vehicle.

