



# CHIPROTECT CLEAR LENS PROTECTORS

## INSTALLATION INSTRUCTIONS

### READ CAREFULLY AND COMPLETELY BEFORE ATTEMPTING INSTALLATION!

1. Gather necessary materials: Supplied squeegee, heat gun or hair drier, mild solvent or isopropyl alcohol, shop rag or paper towel, and all supplied lens protectors.
2. Use towel with prep solvent or alcohol and wipe down all of the lenses thoroughly.
3. Turn on headlights (and fogs if equipped) and allow them to warm up the outside of the lenses.
4. Separate the lens covers from each-other and line them up to insure proper fit and figure out which ones go where. **DO NOT remove the adhesive backing yet!**
5. Once the lenses are warm to the touch, use the heat gun or hair drier to warm a lens protector until it is pliable and warm to the touch.
6. Start in one corner and peel back about an inch of the backing.
7. Line up that corner of the protector on the lens, ensure that it is at the correct angle to follow along (just away from) the edges and push the corner on firmly with the squeegee. **DO NOT TOUCH THE ADHESIVE WITH YOUR FINGERS**, you will leave permanent marks on the lens protector!
8. Pull back the adhesive backing a couple inches at a time and firmly push on the protector away from the corner with the squeegee, then up, and then down; holding the protector at a slight angle away from the lens. **DO NOT let the adhesive touch the lens without pressure from the squeegee**, as you will get visible air bubbles underneath. Toward the edges it may seem as though the material is bunching up, this is normal. **Keep the protector hot** and work the material out evenly, don't force it all into one area.
9. Repeat with each of the supplied lens covers; your lenses are now protected by CHIPROTECT Clear Lens protectors.

*See reverse side for important tips and information about your lens protectors*

## IMPORTANT TIPS AND INFORMATION ABOUT YOUR CHIPPROTECT CLEAR LENS PROTECTORS

Your lens covers may appear hazy and have some small bubbles, this is normal. The product has a 30 to 90 day cure time for all of this to dissipate

Do not wash your vehicle for 24 hours after installation

If the lens protectors were scratched during installation, or become scratched later; (you can avoid scratching during install by using ample heat and making sure the outside of the protector and squeegee are clean) you can use a convertible top window polish or car wax to remove the scratches

CONGRATULATIONS! YOU'VE PROTECTED YOUR LIGHTS WITH CHIPPROTECT CLEAR LENS PROTECTORS