



6233 Elsa Street  
Lakewood, CA  
90713 USA  
Ph: 562-608-8123  
Fax: 562-608-8135

## **M7 Air Plate Diverter (APD) Installation Guide**

### **Tools:**

13mm Socket

### **Procedure:**

- 1) The M7 Air Plate Diverter fits directly in front of the radiator and on top of the front plastic bumper of your car. Remove the (2) 13mm nuts that are holding the metal bumper carrier to the vehicle's frame, you will be re-using these (if you're confused, line the APD up to where it installs and the two nuts you have to remove will be obvious).
- 2) There are (3) strips of double-sided tape on the bottom of the Air Plate Diverter to further keep the APD in place. Remove the backing from the tape before installation.
- 3) Slide the APD onto the two bolts extending through the metal bumper carrier.
- 4) Gently press down onto the APD so that the tape sticks onto the plastic bumper.
- 5) Re-install the (2) 13mm nuts. This should be hand-tight only (16 ft-lb). Any tighter and you risk damage to the APD.

If you need more help, do not hesitate to give us call!

For technical support, please email [techsupport@m7tuning.com](mailto:techsupport@m7tuning.com) or call our office at 562-608-8123 Monday – Friday, 9:00am – 6 pm PST.

Thank you again for your purchase – we appreciate your business.

Enjoy the Ride,

Team M7