KEYHOLE GOVER INSTALLATION GUIDE

TOOL REQUIRED FOR INSTALLATION:

Allen key, flathead screwdriver (in some cases)

Please note that these instructions are not for E46 vehicles. These instructions, however, do apply for all other BMW models. Depending on the model, the installation procedure may be slightly different but will not vary significantly. Instructions for BMW E46 vehicles are available at http://www.bimmian.com

 On the inside of the driver side door, just below the window, there is a large rubber pad.
 Fold back this pad to reveal a screw.
 Use the appropriate allen key to remove the screw completely.



Slide out the exisitng door lock mechanism. (Once the scew is removed, the mechanism will come out with ease.)

Carefully remove the painted plastic cover from the metal locking cylinder by lifting on the two plastic clips and sliding off.

plastic clips and sliding off.

Snap replacement Bimmian.com keyhole cover onto the locking cylinder, and slide it into the hole in the door handle.

Reinstall the screw and refit the rubber pad into the screw hole.

This installation method will provide the security of not having a visible keyhole, while offering you the peace of mind knowing that if for whatever reason you could not access your vehicle using the keyless entry system or through the trunk, you could break off the keyhole cover to expose the locking cylinder.



