

VW V10 Chrome Grill Installation Instructions

1. Remove VW emblem by inserting fingers into emblem and pulling firmly out. The bottom will pop out a bit. Then, while still pulling the bottom out, push downward firmly and the top should pop out. Pull emblem outward and out of grill.



2. Using Torx T25 bit, remove single screw behind hole where emblem was located.



3. Open hood. Using small screwdriver, gently press 4 release tabs near front of hood compartment. These will release the top of the grill.



4. Reach through hole where emblem was, and feel for 4 tabs on bottom of grill (reference new grill for location of tabs). Push tabs down to release bottom of grill.



5. Gently work grill out from side to side. It should slide easily off.



6. Install new grill by firmly pushing it into place. Be sure to set all 8 tabs into their seats at the top and bottom locations where you released them earlier.



7. Replace Torx screw behind emblem hole.
8. Push emblem into place.

You are finished!

