



If the mileage on your stock ECM reaches 0mi and you get the "Engine Will Not Restart" message there is still a way to get it started.

Pull out the starter relay, and put the key in the RUN position. Take a short piece of wire and jump (in the fuse box) between where pins 30 and 87 on the relay would go (if it's labeled 1-2-3-5, jump between pins 3 & 5). Engine will start right back up.

Courtesy of: GDE and Davemd