

Please give copies to all Technical Bulletin

Subject: Radio, Tone, Balance or Fader Knobs Broken or Loose Group: 91


Number: 03-02

Model(s): All with Panasonic Premium

VI Radio

2002 ➤ 2004

Date: Dec. 2, 2003



Condition

Panasonic Premium VI (Radio/CD/Cassette Player) tone/balance/fader knobs broken or loose.

Service

- Replace ALL five knobs -A- with 5 knobs from kit Part No: ZVW 828 002A.
 - Discard knobs removed from radio.

Note:

To prevent repeat repair to a different knob at a later date. It is important to install ALL 5 knobs from the kit.

C 91–03–02 1 of 1